

POLE CHOKER INSPECTION CHECKLIST

1. Choker Strap

- ✓ When inspecting the yellow choker strap, you will want to check for the following items:
 - Red wear indicator. In the event the strap is worn to the point the red wear indicator is showing, remove from service.
 - Stitching. Inspect all stitching for excessive wear including stitching that is broken or coming undone.
 - Cuts, Tears and Defects. Inspect to ensure there are no cuts, tears or other defects in the yellow choker strap. Due to several contributing factors of use, there is the possibility of furring that might occur on the yellow choker strap. This will not impact the integrity of the product as long as the red wear indicator is not showing.

2. Pole Strap

- ✓ When inspecting the pole strap, you will want to check for the following items:
 - Red wear indicator. In the event the strap is worn to the point the red wear indicator is showing, remove from service.
 - Rivets. Inspect all rivets for damage.
 - Hardware. Inspect the hardware of the adjustment buckle to ensure it works as it is intended to be used.
 - Cuts, Tears and Defects. Inspect to ensure there are no cuts, tears or other defects in the pole strap.

3. Pole Choker Roller Adjuster

- ✓ When inspecting the PC Roller, you will want to check for the following items:
 - Housing. Inspect the housing for any signs of damage including, but not limited to cracks, holes, etc.
 - Roller and Pin. Check to ensure that both operate correctly. The roller should be able to be moved in either direction to allow for the yellow choker strap to flow freely while on it. The pin must be secure, while also showing some signs of movement as the roller spins.
 - Corrosion. Inspect for any corrosion or build-up of residue that might restrict the PC Roller's ability to perform its intended function.
 - Teeth. Inspect the teeth to ensure they have not become chipped or show excessive wear.
- ✓ **The PC roller can be lubricated using non-penetrating oil such as WD40.

4. Ejector Snap

- ✓ When inspecting the PC Roller, you will want to check for the following items:
 - Latch. Inspect to see if the spring is weakened or showing signs of being defective.
 - Corrosion. Inspect for any corrosion or build-up of residue that might restrict the Ejector Snaps ability to perform its intended function.
- ✓ **The ejector can be lubricated using non-penetrating oil such as WD40.

5. Triangle Connector

- ✓ The triangle connector should be checked for free movement along the pole strap and free from damage including any cracks or breaks in the metal.

6. Adjustment Buckle

- ✓ Check for ease of adjustment and function also inspect the webbing at the point where it comes into contact with the buckle. If the red wear indicator is showing on the pole strap then remove from service.

7. Pole Strap Snap Hooks

- ✓ When inspecting the snap hooks, you will want to check for the following items:
 - Hardware. Inspect that there isn't any visible signs of damage to the housing of the snap hook.
 - Operation. The snap hook must open and close as it is intended.
 - Corrosion. Inspect for any corrosion or build-up of residue that might restrict the snap hooks ability to perform its intended function.

8. All Weather Grippers

- ✓ When inspecting the all-weather grippers, you will want to check for the following items:
 - Teeth. Inspect for excessive wear to the teeth on the gripper as indicated by the gripper gauge.
 - Housing. Inspect the housing of the grippers for any damage or evidence of trauma.
 - Corrosion. Inspect for any corrosion or build-up of residue that might restrict the all-weather grippers' ability to perform its intended function.

9. Pole Strap / Choker Strap Connector

- ✓ When inspecting the choker strap connector, you will want to check for the following items:
 - Buckle. Inspect the buckle to ensure that it operates as intended and there are no cracks, breaks, or visible metal fatigue.
 - Corrosion. Inspect for any corrosion or build-up of residue that might restrict or prevent the free movement along the pole strap.

JELCO

Date	Serial #	UPC:
Product Inspection Sheet		
Pole Choker Checklist		
		Pass = <input checked="" type="checkbox"/>
		Fail = <input type="checkbox"/>
1.	Choker Strap	
2.	Pole Strap	
3.	Pole Choker Roller Adjuster	
4.	Ejector Snap	
5.	Triangle Connector	
6.	Adjustment Buckle	
7.	Pole Strap Snap Hooks	
8.	All Weather Grippers	
9.	Pole Strap / Choker Strap Connector	
Comments		